
SIMPLYSNAP SYMBOLS · AUTO DEALERSHIP

Devices used in the SimplySnap auto dealership application guide and its one-line drawing (SS-OL-AUTO-01).




SS450

SS450 SITE CONTROLLER

SS450-002 · indoor






CBS

CBS SITE CONTROLLER

CBSSW-450-002 · outdoor enclosure





TL7-HV(G)

TWIST-LOCK CONTROLLER

Type A poles · ANSI C136.41 7-pin






CSEN1

COMBO SENSOR CONTROLLER

Type B poles · Zhaga Book 18





DIM10-220(-F)


BOLT-ON CONTROLLER

Wall packs, floods & other fixtures

External or internal (-F) antenna



DIM10-220 DIM10-220-F



SNV-SW-02

WIRELESS 2-BUTTON SWITCH

SW-1 · indoor wall box



1. Row 1: tagged symbol (model tag below the device). Row 2: untagged icon for tight plans. Symbols are not to scale. Each is drawn in the same 1-inch square with matching line weights, so they look consistent when placed at the same size.

2. Use one site controller per site: the SS450 for indoors, or the CBS where an outdoor-rated enclosure is needed.

3. In Bluebeam Revu: place a symbol, set its Subject to the model number, then right-click › Add to Tool Chest so counts roll up in the Markups List.

4. The DIM10-220 takes an external antenna (sold separately, shown fitted); the DIM10-220-F has an internal antenna (no antenna lead). Both icons shown in row 2.